

Unlimited eSIM User Guide



worldmobile

Before Every Trip:

Turn on your **eSIM**; you'll receive an SMS.

Click the link to check your Balance & Top-up.

iPhone: Settings > Cellular > **eSIM** (located below 'Primary').

Samsung: Settings > Connections > SIM manager > **eSIM**

Upon Landing Abroad:

1. Turn on your **eSIM** and turn off your Home SIM.

2. Activate **Data roaming** (WhatsApp will work normally).

iPhone: Settings > Cellular (or Mobile Data) > **eSIM**

Samsung: Settings > Connections > Mobile networks

Calling Worldwide:

1. Get **+44** Number: Dial any number to receive it via SMS.

2. Dialing Out: Call directly from your contacts or dial:

+ country code - area (without 0) - phone number.

3. Receive SMS: On your **+44** number.

Troubleshooting:

- 1. General Issues:** Restart your phone, activate **eSIM**, disable Home SIM.
- 2. Locked Phone:** If prompted for an unlock code, contact your carrier to obtain it or use an unlocked phone as a Wi-Fi hotspot.
- 3. Calling Issues:** Dial: ***126*** country code - area (without **0**) - phone no.**#**
- 4. Network Issues:** Manually select another network until connected.
iPhone: Settings > Cellular > **eSIM** > Network Selection > Turn off Auto.
Samsung: Settings > Connections > Mobile networks > Network operators > **eSIM** > Turn off Auto.
- 5. Internet Issues:** Enable **Data Roaming**, and follow point 4. Set-up APN:
iPhone: Settings > Cellular > **eSIM** > Cellular Data N. > APN: **mobiledata**
Samsung: Settings > Connections > Mobile net. > Access Point Names > **eSIM** > Add (+) > Name: **worldmobile**, APN: **mobiledata** > Save & Select.

For more information visit: www.worldmobile.com/support